

## INSTRUCTIONS FOR

# CA FINISHING

## MATERIALS REQUIRED:

Thin CA glue  
Eye protection  
Hut ultra gloss  
Accelerator with spray pump  
Micro mesh (1,500 to 12,000)  
Non-stick bushings  
Shop towel

### STEP 1

After sanding, replace your metal bushings with non-stick plastic CA bushings

### STEP 5

Sand with micro mesh from 1,500 to 12,000 grit with light pressure to remove the top layer of glue

### STEP 2

At a medium speed, apply a small amount of CA glue to a clean shop towel

### STEP 6

Use a small amount of HUT Ultra Gloss on a clean shop towel to apply a top coat to your blank

### STEP 3

With the lathe turning, wipe the glue onto the blank and follow with a spray of accelerator over top

### STEP 7

Use a clean portion of the towel to buff off the polish to bring up a durable shine

### STEP 4

Repeat the previous step with layers of glue and accelerator 8-10 times